

Firmware Update Readme

DiDiT High-End
04-2018

HOW TO UPDATE THE DAC212 FIRMWARE

Check for the needed files:

- DAC212_HWxxx_Vxxx.hex
- DiDiT_Loader.exe

Unzip the DAC212 Update folder to your desktop.

Check firmware:

DAC212_HW1.14x_Vx.xx means the file is ONLY for DAC212 Hardware revisions 1.14.x

Follow the next steps:

1. Unplug the powercord.
2. Connect the DAC212 mirco-usb to a windows pc.
3. Put an open bend paperclip in the 1.5mm hole near the micro-usb port.
Push it untill you feel a click. Hold this position.
4. Replug the powercord.
5. Check for green blinking led at the front of the unit (boot mode).
Remove the paperclip.
6. Start the DiDiT Loader software.
7. Check in software if {Device:} is DAC212.
8. Push in software the [Connect] button. Connection will be shown in the window, if not check cables.
9. Push in software the [Load File] button and load the DAC212_HWxxx.HEX file
10. Push in software the [Program] button and firmware will be loaded,
see window.
11. Disconnect the DAC212 from power and micro-usb cable.
12. Replug powercord and enjoy.